



AstroSafari Cupholder – Installation Instructions

1. Remove protective film from your AstroSafari Cupholder Insert as indicated in the picture below.

NOTE: The acrylic units have film on both sides, the aluminum composite units have film only on the aluminum side.



2. Apply the three included Velcro dots to your cupholder insert – one at each side and one in the middle – as shown in the picture below.



3. Goto your van and clean the cupholder surface on the center console with rubbing alcohol and let dry.
4. Once dry – align the holes on your cupholder insert with the holes on the cupholder and place your cupholder insert on the cupholder surface. Press down firmly at each Velcro point to promote adhesion.



TIP: Leave put for 24 hours to promote adhesion between the Velcro and the cupholder and cupholder insert.

5. Enjoy your now functional AstroSafari Cupholders!!

TIP: Don't like the look of the velcro on your acrylic cupholder? Clear double-sided tape (3M VHB is my favorite!) or two well-placed screws work, too!

THANKS FOR MAKING YOUR VAN MO' BETTER WITH IRONCLOUD METALWORKS!

CHECK OUT OUR WEBSITE AND JOIN OUR MAILING LIST FOR MORE PRODUCTS AND RELEASE INFORMATION

WWW.IRONCLOUDMETALWORKS.COM

WE'D LOVE TO SEE PHOTOS OF YOUR INSTALL – SHARE THEM WITH US ON INSTAGRAM

[@IRONCLOUDMETALWORKS](https://www.instagram.com/IRONCLOUDMETALWORKS).

